

# Service Manual

Mini Cassette

**DOLBY B NR** Stereo Radio Cassette Player

## RQ-SX25V



### Colour

(K).....Black Type

### Area

(GH).....Hong Kong.

\* Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.  
"Dolby" and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

## AR10 Mechanism Series

## Specifications

### General:

#### Power Requirement:

Battery; DC 1.5V one "AA" size battery (not included)  
(Panasonic R6, LR6 or equivalent not included)  
Rechargeable Battery; DC1.2V with an included  
Panasonic Rechargeable Battery (RP-BP61SYS1)x1

#### Power Output:

4mW+4mW...RMS (max.)

#### Output Jack:

Headphones; 32 ohm (stereo mini jack diameter 3.5)

Dimensions: 108.8 (Wide) / 77.0 (High) / 20.3 (Depth) mm

Weight: 164g (with rechargeable battery)

Charger: (RP-BC155AEY) (included)

Input; AC230V, 50Hz, 4VA

Output; DC 340mA, 1.2V

#### Playing time:

(When used in hold mode, at 25 °C on a flat and stable surface.)

The play time may be shorter depending on the operating conditions.

Panasonic Dry cell battery: R6/About 13h, LR6/About 30h

Rechargeable battery: About 10h

Panasonic Dry cell battery (R6) with rechargeable batteries: About 23 h

Panasonic Dry cell battery (LR6) with rechargeable

batteries: About 40 h

Recharging time: About 2 hours

### Radio:

#### Frequency Range:

AM; 522-1629 kHz (9 kHz steps/Japan mode)

520-1710 kHz (10 kHz steps mode)

FM; 87.5-108.0 MHz (AM 9kHz/10kHz steps mode)

76.0-90.0 MHz (Japan mode)

(0.1MHz steps)

TV; 1-12ch (Japan mode only)

Intermediate Frequency: AM; 450 kHz, FM; 10.6 MHz

Sensitivity: AM; 316.2µV/m/0.1mW output

FM; 4.5µV/0.1mW (-3dB Limit sense)

TV; 5.0µV/0.1mW (-3dB Limit sense)

### Cassette Player:

Frequency Range (Normal/High/Metal): 40~18,000Hz

Motor: Electrical governor motor

Track System: 4-track 2-channel stereo playback

Tape Speed: 4.8cm/s

**Note:** Design and specifications are subject to change without notice.

Weight and dimensions are approximate.

### ⚠ WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

# Panasonic®

© 1996 Matsushita Electric Industrial Co., Ltd.  
All rights reserved. Unauthorized copying and distribution is a violation of law.

## Contents


	Page		Page
Accessories .....	2	Schematic Diagram .....	21~26
Location of Controls .....	2	Block Diagram .....	27
Power Sources .....	3	Terminal Guide of IC's, Transistors and Diodes .....	27
Before Use .....	3	Printed Circuit Board	
Preset Tuning .....	3	and Wiring Connection Diagram .....	28~31
Listening to The Radio .....	4	Terminal Guide .....	32, 33
Cautions .....	4	Cabinet Parts Location .....	34
Listening to Tape .....	5	Replacement Parts List .....	35, 36
Remote Control Operation .....	6	Resistors and Capacitors .....	37~39
To Change the Tone .....	6	Mechanism Parts Location .....	39
Service Mode .....	7~10	Replacement Parts List .....	39, 40
Mechanism Block Replacement Procedure .....	11	Supply of Rechargeable Battery as Replacement Parts .....	40
Operation Checks and Main Component		Caution in Use of Rechargeable Battery .....	40
Replacement Procedures .....	12~18	Packaging .....	40
Mesurements and Adjustments .....	19, 20		

## Accessories

Stereo earphones.....1pc.  
(RFEV316P-KS)



Remote controller.....1pc.  
(RFEV001PVKS)




Charger.....1pc.  
(RP-BC155AEY)




Rechargeable battery.....1pc.  
(RP-BP61SYS1)



Rechargeable battery  
carrying case.....1pc.  
(RFA0475-Q)



Dry cell battery case.....1pc.  
(RFA0617-H)




Carrying bag.....1pc.  
(RFC0043A-K)




## Location of Controls

### • Remote Controller



### • Main Unit



## Power Sources

### A Rechargeable battery

For its initial use after purchasing or after a long time interval (more than three months), be sure to recharge the rechargeable battery. Normally 2 hours recharging will give approximately 10 hours tape playback (at 25°C).

### B Dry cell battery

#### To extend the playback time

Install both types of battery (rechargeable and dry cell battery) in the unit.

#### When the battery becomes weak

The OPR/BATT indicator will dim or turn off. Recharge the rechargeable battery or replace the dry cell battery with new one.

## Before Use

### D Connecting the stereo earphones and remote controller

Unless the earphones and remote controller are firmly inserted into the  $\Omega$  jack, the sound may become intermittent, or operation using the remote controller may become impossible.

#### Illuminated remote controller

Pressing any button on the remote controller or the unit lights the display for approximately 5 seconds, enabling easy use even in dark areas.

#### Concerning the hold function

This function prevents the unit from operating even if one of the buttons is pressed in error.

#### To use the hold function

Set HOLD to the hold position (hold state).

- Both the main unit and remote controller have a HOLD switch, and each of them works individually.

## Preset Tuning

Frequencies of up to 18 radio stations (9 each AM and FM) can be stored in the memory.

Since the cord of the earphones acts as an FM antenna, connect the earphones when storing frequencies of FM stations in the memory.

Preparation: Release the hold state.

#### Auto memory function

Broadcast frequencies are automatically stored in the memory.

- Press RADIO/BAND to switch on the power.
- Press MODE to display "MEMO".
- Press and hold AUTO.

The frequencies of the each band are stored in order from small to large numbers of the frequencies in the memory.

#### When "ERROR" appears on the display:


Any frequency could not be stored in the memory. Preset favorite stations manually. (See below.)

#### Manual memory function

- Press RADIO/BAND to switch on the power.
- Press MODE to display "MEMO".
- Press RADIO/BAND to select the band.
- Press and hold MEMORY to have broadcast frequency indicated (flashing), and then press + or - to select the broadcast frequency.
- Press MEMORY to have "M" and memory number indicated (flashing).
- Press + or - to select the memory number.
- Press MEMORY.

#### To erase the unnecessary memory channel

- Press RADIO/BAND to switch on the power.
- Press MODE to display "MEMO", and then press + or - to select the memory number to remove.
- Press and hold MEMORY to have broadcast frequency indicated (flashing).
- Press both + and - to display "-----" (flashing).
- Press MEMORY.



## ■ Listening to the Radio ( F )

- 1 Release the hold state.
- 2 Press RADIO/BAND to switch on the power.
- 3 Press MODE to display "MEMO" (MEMO mode) or not (free mode).

MEMO mode: To listen to the preset memory channel

Free mode: To listen to the desired station (not have been preset)

- 4 Press RADIO/BAND to select the band.

Each press changes the indication between AM and FM.

- 5 Press + or - to select the desired station.

MEMO mode: Preset memory number becomes higher (+) or lower (-).

Free mode: Broadcast frequency becomes higher (+) or lower (-).

- 6 Adjust the volume.

### To stop listening:

Press OFF.

### Auto tuning: (except MEMO mode)

Press and hold + or - until the displayed frequency begins to change. The changing will automatically stop if a broadcast frequency is located.

To stop automatic tuning, press + or - again.

### ■ To select the stereo/monaural of the FM

Set STEREO MODE to ST or MONO.

### When there is a noise during FM reception:

Set STEREO MODE to MONO.

Though the sound becomes monaural, noise is reduced.

### ■ To obtain good reception

#### When listening to AM broadcast: G

As the built-in ferrite antenna works, try various directions to catch optimum reception.

#### When listening to FM broadcast:

As the cord of the earphone acts as an antenna, use it as extended as possible, not coiled.

### ■ To convert the AM frequency step

At the time of purchase, the AM band frequency changes by the step of 9 kHz. It can be converted from 9 to 10 kHz to receive radio stations in a different country or area, which cannot be tuned in with the 9 kHz step.

1. Press RADIO/BAND to switch on the power.
2. Press and hold MODE for more than five seconds.
3. Press + or - to select the step.

Each press changes the indication among "UAM10", "EAM9" or "J".

"UAM10": 10 kHz step. For the use in North and South America or part of Southeast Asia.

"EAM9": 9 kHz step. For the use in Southeast Asia or Europe.

"J": 9 kHz step. For the use in Japan.

4. Press and hold MEMORY for more than five seconds.

### To return to the previous frequency step:

Follow steps 1 through 4 above.

### Note:

Converting the frequency step erases the stations previously stored in the memory.

### Area bank function (only for Japan mode "J"):

This unit equipped with an area bank function, allowing you to easily listen to previously stored stations in any of the 41 regions and JR (those JR Shinkansen lines equipped with on-board FM broadcasts).

Auto area bank function automatically select the area number according to the region where you are.

1. Press RADIO/BAND to switch on the power.
2. Press MODE to display "AREA".
3. Press and hold AUTO.

## ■ Cautions

- To avoid product damage, do not expose this product to rain, water or other liquids.
- Avoid using or placing this unit near sources of heat. Do not leave it in an automobile exposed to direct sunlight for a long period of time with the doors and windows closed, as this may deform the cabinet.

### Precautions for Listening with the Headphones

- Do not play your headset at a high volume. Hearing experts advise against continuous extended play.
- If you experience a ringing in your ears, reduce volume or discontinue use.
- Do not use while operating a motorized vehicle. It may create a traffic hazard and is illegal in many areas.
- You should use extreme caution or temporarily discontinue use in potentially hazardous situations.
- Even if your headset is an open-air type designed to let you hear outside sounds, don't turn up the volume so high that you can't hear what's around you.

### Rechargeable battery and charger

- Use only the included charger when recharging.
- During recharging, it is normal for the charger and the rechargeable battery to become slightly warm.
- Do not leave the charger turned on for more than 12 hours at one time, otherwise, the rechargeable battery life may be shortened.
- Avoid recharging or placing the rechargeable battery near sources of heat or humidity.
- The included rechargeable battery can be recharged about 300 times. After that, its operation time becomes shortened. That's time for replacing the rechargeable battery.

### Dry cell battery and rechargeable battery

- Load new battery with their polarities (⊕ and ⊖) aligned correctly.
  - Do not apply heat to batteries, or internal shortcircuit may occur.
  - If this unit is not to be used for a long period of time, remove the batteries and store them in a cool and dry place.
  - Remove spent batteries immediately.
- Do not peel of the plastic covering on the rechargeable battery. Short-circuiting may result which is dangerous.

### Carrying batteries around


When putting dry batteries and rechargeable batteries in a pocket or bag ensure that no other metal objects such as a necklace are placed together with them. Contact with metal may cause short-circuiting which, in turn, may cause a fire. The same caution needs to be heeded with the battery case containing a dry battery. When carrying the rechargeable battery around, be absolutely sure to place it inside the included rechargeable battery case.

### Endless tapes

Failure to operate these tapes correctly may cause the tape to wind around the revolving parts. For this unit, it is recommended to use the tape which is appropriate to the auto reverse mechanism.

### H Cassette compartment cover

If the catch is in the position shown in the figure ①, the cassette compartment cover won't close. The compartment cover may be bent out of shape if an attempt is made to forcibly close the cover. If this occurs, slide OPEN so that the catch is in the position shown in the figure ②.



## ■ Listening to Tape ( I )

This unit is equipped with an auto tape select function, so you can use normal, high or metal position types of tape.

### 1 Insert a cassette tape.

Closing the cover, the tape slack will be wound automatically and playback will be expected to start from the side A.

### 2 Release the hold state.

### 3 Press ◀▶.

### 4 Adjust the volume.

#### To stop playback:

Press ■.

#### To change the tape direction

Press ◀▶ during playback.

#### Automatic side A/B detection function:

This unit has a function that detects which side is being played, using the cutout screw hole on side A of the cassette. If there is no cutout on the cassette, the cutout is on side B, or depending on other features of certain cassette types, the side may not be correctly detected.

#### To change the play mode

Select the position of the play mode selector (ON/↻, OFF/↶).

**ON/↻:** Both sides of the cassette are played continuously. Blank-skip function works.

**OFF/↶:** The forward and reverse sides of the cassette are played once and then the playback stops. Blank-skip function doesn't work.

#### Blank-skip function (B.S):

When a silent part of more than 13 seconds is detected during playback, fast-forwarding automatically starts and then playback of the opposite side of the cassette starts from the beginning.

- When playback is started at the point close to the end of the last song, it may not work properly.
- When small sound continues for more than 13 seconds, the unit may start fast-forwarding. When you listen to a classical music, set the selector to the OFF/↶ position to release the Blank-skip function.

#### To play the tape with Dolby NR

Set □□ NR selector to ON.

#### To fast forward (FF) or rewind (REW)

Press FF or REW in the stop mode.

#### To find the beginning of a song (TPS: Tape Program Sensor)

Press FF or REW during playback.

You can skip as many songs as the number of times the button is pressed (up to 9 times).

FF: You can skip forward (FF TPS).

REW: You can skip backward (REW TPS).

#### ■ To repeat a current song (ONE-REPEAT)

(Available only from the remote controller)

Press and hold ■ 1-RPT/EQ on the remote controller during playback.

#### To cancel the ONE-REPEAT:

Press and hold ■ 1-RPT/EQ once more.

ONE-REPEAT is also cancelled when tape operations are switched.

#### ■ To search a song on the cassette (Intro-scan)

(Available only from the remote controller)

Allows you to listen to the beginning portion (intro) of the songs for about 10 seconds each, in order.

Press and hold FF/+ or REW/- in the stop mode.

FF/+ : Fast forward starts.

REW/- : Rewind starts.

#### To cancel the Intro-scan and resume normal playback:


Press main button once.

#### Notes:

Since making use of the silent part between songs, the TPS, ONE-REPEAT and the Intro-scan function may fail to function properly in the following situations:

- When the silent part between songs is less than 4 seconds or has noise.
- When the next silent part is less than 10 seconds away.
- When there is a long silent part or particularly low or small sound in the song.

During TPS or Intro-scan, the unit automatically reverses when the end of the cassette tape is reached and operation continues. However, if the end of a cassette tape is detected three times, the tape automatically stops.



## Remote Control Operation

Before using VOL on the remote controller, be sure to adjust the volume control on the main unit. "5-7" is the average volume level.

- : Press.
- : Press and hold.

Confirmation beep can be heard as shown in the figure.

### Operating the radio

#### Operating the cassette player

The beep tone, which is emitted when the button is pressed once in the stop mode, indicates that a cassette is not inserted.

## To Change the Tone (M)

(Available only from the remote controller)

Every time you press ■ 1-RPT/EQ during playback or radio reception, the EQ effect will change as follows in turn.

#### NOR:

The EQ effect is cancelled.


#### S-XBS:

Boosts the low frequency range.

- If the sound distortion occurs, turn down the volume.

#### TRAIN:

Gives a more natural quality to the sound and reduces strain and fatigue when you listen for a long time. It also cuts down the audible level of sound which disturbs people around you.



## Service Mode

This unit and its remote controller have a service mode which can be used to locate errors and faults (the remote controller and stereo earphones are detachable). Refer to this document to provide service and repairs.

### Quick reference for service mode errors

The following table shows error identification criteria:




Service mode		Component	Judgment criteria			
(1)	Unit and stereo earphones test	Unit	OK	OK	NG	NG
		Stereo earphones	OK	NG	OK	NG
		Location of fault	No faults	Stereo earphones	Unit	Unit and stereo earphones
(2)	Remote controller and stereo earphones test	Remote controller	OK	OK	NG	NG
		Stereo earphones	OK	NG	OK	NG
		Location of fault	No faults	Stereo earphones	Remote controller	Remote controller and stereo earphones

### (1) Checking the unit and stereo earphones



#### Preparations:

1. Firmly plug the stereo earphones into the headphones jack.
2. Install fully-charged rechargeable or R6/ LR6 dry cell batteries into the battery compartment.
3. Load a music tape into the unit and close the cassette compartment lid.
4. Make sure the HOLD button on the unit is off.
5. Set the Stereo Mode, Blank Skip/Reverse Mode switch to "OFF/ 

#### • Location of controls and connections on the unit



(Continued on the next page.)



**Note:** Once the RADIO/BAND ON button is pressed and the unit stops, it exits the service mode.



• Troubleshooting

Location of fault	Symptom	Faulty component
A	The unit fails to enter play mode or change the direction of play when the PLAY/DIRECTION (◀▶) button is pressed.	Fault in S7(PLAY/ DIRECTION), S11(RADIO OFF/ STOP) or motor.
B		
C	The unit fails to enter fast forward mode when the FF/+ button is pressed.	Fault in S8( FF/+ ).
D	The unit fails to enter rewind mode when the REW/- button is pressed.	Fault in S5( REW/ - ).

**(2) Checking the remote controller and stereo earphones**


**Preparations:**

1. Firmly plug the remote controller into the headphones jack.
2. Firmly plug the stereo earphones into the remote controller.
3. Install fully-charged rechargeable or R6/ LR6 dry cell batteries into the battery compartment.
4. Leave the cassette compartment lid closed, with no tape loaded in the compartment.
5. Make sure the HOLD buttons on the unit and remote controller are off.



**Note:** The remote controller will continue to display the information last called up in service mode. Once the batteries are removed from the unit, it exits the service mode.

**• Location of controls and connections on the remote controller**



**• Procedure for testing the remote controller**

Remote controller operation	Enters service mode. →	Press main button. →	Press FF button. →	Press REW button. →	Press One-repeat/ EQ button.
Normal information display					
	"PLAY" is displayed on the display panel.	"FF" is displayed on the display panel.	"REW" is displayed on the display panel.	"522" is displayed on the display panel.	After a single tone in the both channels of the stereo earphones hear, the display panel glows blue and "OFF" is displayed for about 5 sec.



• The remote controller is functioning normally if it displays information as shown in the table above.

### (3) Checking the amplifier block

The following procedure is only necessary if a fault in the amplifier block was detected during testing of the unit or stereo earphones.

Preparations:

1. Make sure the HOLD button on the unit is off.
2. Follow the steps described in Step 12 of checking for the main P.C.B. on page 14.
3. Firmly plug the stereo earphones into the headphones jack.



- Notes:**
- The motor is rotating when do not the RADIO/BAND ON button but the RADIO OFF/STOP(■) button.
  - Push the RADIO/BAND ON button after the motor stopped.
  - In service mode, the unit stays in fast forward mode until the RADIO OFF/STOP(■) button is pressed, at which time the unit exits service mode.

## ■ Mechanism Block Replacement Procedure


### • Mechanism block replacement

Repair parts are supplied in the form of a mechanism block ass'y, from which the head block, motor, and capstan belts (1) and (2) are removed.

Before replacing the mechanism block, perform the following steps :


#### Preparations

Remove the head block, motor, and capstan belts (1) and (2) from the unit, and install them in the mechanism block ass'y (for disassembly, refer to Operation Checks and Main Component Replacement Procedure).



Mechanism block

Fig.1



Mechanism block ass'y

Fig.2


※ No adjustment is needed after replacement.

### • Head block replacement

Repair parts are supplied in the form of a complete head block ass'y, which includes the head, head arm spring, and pinch roller arms (F) and (R) .

The head arm spring and pinch roller arms can also be supplied separately on request.

※ No head azimuth adjustment is needed.



Head block ass'y

Fig.3

## ■ Operation Checks and Main Component Replacement Procedures

**NOTE**


1. This section describes procedures for checking the operation of the major printed circuit boards and replacing the main components.
2. For reassembly after operation checks or replacement, reverse the respective procedures. Special reassembly procedures are described only when required.
3. Illustrated screws are equivalent to actual size.
4. [ ] indicates parts No.

● **Contents**


	Page.
1. Checking for the main P.C.B. ....	12~15.
2. Replacement for the motor and capstan belt. ....	15,16.
3. Replacement for the intermediate ornament (A), intermediate ornament (B), intermediate ornament (C) and open knob ass'y. ....	16,17.
4. Replacement for the head block ass'y. ....	17,18.

### 1. Checking for the main P.C.B.

〈Checking the main P.C.B. (Front side)〉



• Check the main P.C.B. (Front side) as shown below.



**NOTE**

The rechargeable battery should be recharged fully.



a

[RHQ0061-K]




b

[RHQ0059-K]


<Removal for checking the main P.C.B. (Back side)>




[RHQ0060-N]



**Step 7**  
Unsolder each point.




**Step 10**  
Remove the intermediate ornament ass'y.



**NOTE**

When the main P.C.B. is removed, the rechargeable battery terminal (+) and battery cover will also be removed.

- Check the main P.C.B. (Back side) as shown below.




### ■ Operation Checks

- Confirm that the beeper sounds once by headphones when depressing the RADIO OFF/STOP (■) button more than 5 sec. under above condition, and then depress the RADIO OFF/STOP (■) and FWD (FF) buttons at same time more than 5 sec.. Keep the finger away from those buttons after that, so the FF mode will be operated. For more information about mode setting, refer to "(3) Checking the amplifier block" of service mode on page 10.


**Notice for installing the knobs and assembling the cabinet ass'y**

- Make sure the bosses of switch are fit in the switch knobs when assembling.




**2. Replacement for the motor and capstan belt**

- Follow **Step 1** ~ **Step 4** , **Step 6** ~ **Step 11** in item 1 on pages 12 and 13.





(Upset the unit)

**a**  
[XQS14+A2FZ]





**Installing the capstan belt (1)**

- When install the capstan belt (1) to motor, push up the motor by insert the non-magnetic material sheet between bottom of the motor and the chassis, and install the capstan belt (1) between top of the motor and the coil P.C.B..



**3. Replacement for the intermediate ornament (A), intermediate ornament (B), intermediate ornament (C) and open knob ass'y**


- Follow **Step 1** ~ **Step 4** in item 1 on page 12.




	<b>a</b>
[RHE5119YA]	
	<b>b</b>
[XQN14+BG4FZ]	


4. Replacement for the head block ass'y

- Follow **Step 1** ~ **Step 4** in item 1 on page 12.
- Follow **Step 1** ~ **Step 3** in item 3 on page 16.






[RHQ0032-K]





a, b, c  
[RHD14047]

**Assembly procedures for head block ass'y after replacement**



## Mesurements and Adjustments

### ● Preparation for Adjustment

Follow "step 1~ step 5" in item on page 12.

### ● Measurement Condition

- |   |   |
|---|---|
| 1. Set volume control to maximum.                                   | 4. Release the hold state.              |
| 2. Set Dolby NR switch to OFF.                                      | 5. Set power source voltage to 1.5V DC. |
| 3. Set RADIO/BAND switch to ON (FM stereo, AM/FM/TV RF adjustment). |   |

### ● Measuring Instruments and Special Tools

- |                                  |                      |
|----------------------------------|----------------------|
| 1. Signal generator (AM, FM, TV) | 3. Frequency counter |
| 2. Oscilloscope                  |                      |

### ● Radio Section

#### ● AM / FM / TV RF Adjustment

Band	Signal Generator		Display Setting	Indicator (Oscilloscope)	Adjustment Point	Remarks
	Connection	Frequency				
AM	Fashion a loop of several turns of wire and radiate a signal into the loop ant. of receiver.	594kHz	594kHz	Headphones jack (32Ω) (Refer to Fig.2)	<b>L11</b> (Refer to Fig. 3)	Adjust <b>L11</b> for maximum output.
FM	<b>TP28</b> ... (+) <b>TP27</b> ... (-) (Refer to Fig. 1)	90MHz	90MHz	Headphones jack (32Ω) (Refer to Fig.2)	<b>CT1</b> (Refer to Fig. 3)	Adjust <b>CT1</b> for maximum output.
TV	<b>TP28</b> ... (+) <b>TP27</b> ... (-) (Refer to Fig. 1)	197.75MHz (8ch)	8ch	Headphones jack (32Ω) (Refer to Fig.2)	<b>CT2</b> (Refer to Fig. 3)	Adjust <b>CT2</b> for maximum output.

#### ● FM Stereo Adjustment

Item	Input	Output	Adjustment Point	Procedure
FM Stereo adjustment	76MHz, 66dB <b>TP28</b> ... (+) <b>TP27</b> ... (-) (Refer to Fig. 1)	<b>TP202</b> ... (+) <b>TP27</b> ... (-) (Connect a 220kΩ-330kΩ resistor between the test points <b>TP202</b> and <b>TP27</b> .) (Refer to Fig. 1)	<b>VR3</b> (Refer to Fig. 2)	1. Set STEREO MODE switch to ST. 2. Adjust <b>VR3</b> for 19 kHz ± 50 Hz reading on frequency counter.

#### ● Tape Section

Item	Test Tape	Measurement Point	Adjustment Point	Procedure
Tape speed adjustment	QZZCWAT (3kHz, -10dB)	Connect the frequency counter to Headphones jack (32Ω) (Refer to Fig.1)	<b>VR402</b> (Refer to Fig. 3)	Playback the central part of the tape and adjust <b>VR402</b> so that the tape speed is as follows. Forward: <b>3000±20Hz</b> Reverse: <b>2970~3080Hz</b> Make sure that the frequency range is within ±60Hz for between "Forward" and "Reverse" mode.

**Note:** The playback head is supplied on the head arm assembly. (See the "Mechanism Parts Location" on page 39.)  
The assembly requires no adjustment.

● Adjustment Point

Note: This printed board diagram shows a view the layer 4 side of pattern drawing (A) as shown in Fig. 1..




Fig. 1




Fig. 2

Note: This adjustment points shown a front view of the IC5 mounting surface as shown in Fig. 3.




Fig. 3


## Schematic Diagram (See parts list on pages 35~39.)

● This schematic diagram may be modified at any time with development of new technology.)

### Notes:

- **S1** : Tape A/B side det. switch.
- **S3** : MODE select switch.
- **S4** : MEMORY switch.
- **S5** : - / REW switch.
- **S7** : Play (◀▶) switch.
- **S8** : + / FF switch.
- **S9** : AUTO switch.
- **S10** : RADIO ON / BAND select switch.
- **S11** : RADIO OFF/ Stop (■) switch.
- **S12-1** : Tape IN/OUT det. switch in "OUT(OFF)" position.  
[IN(ON)... Tape in, OUT(OFF)...Tape out]
- **S12-2** : Tape detector (METAL/NORMAL) switch in "OFF (METAL)" position.
- **S15** : Dolby noise reduction (NR) switch in "OFF" position.
- **S16** : Mech. det.(FWD/STOP/REV) switch in "REV" position.
- **S17** : B.S./REV MODE/STEREO MODE switch in "OFF/ MONO" position.
- **S18** : HOLD (HOLD) switch in "OFF" position.
- **VR1** : Volume adjustment.
- **VR3** : FM stereo adjustment.
- **VR402** :Tape speed adjustment.
- DC voltage measurements are taken with electronics voltmeter from negative terminal of battery.
- No mark...Playback, FM / TV... < > , AM... ( )
- Current consumption of tape playback and radio mode: About 64 mA.

### ● Signal line




### ● Check Point of Signal

Check Item		TEST POINT
Head Input	L ch	TP1 , TP2
	R ch	TP3 , TP4
	VREF	TP5
Dolby Output → VR Input	L ch	TP6
	R ch	TP7
	COM	TP8
VR input → VR Output	L ch	TP9
	R ch	TP10
	COM	TP8
Power amp. → Headphones Output	L ch	TP11
	R ch	TP12
	COM	TP13
DC-DC Converter (Booster)	2.4V output	TP14
	GND	TP15
Photo Coupler (End)	Pulse output	TP16

## ●EEPROM ( Electrically Erasable Programmable Read Only Memory)


● The unit contains a rewritable non-volatile EEPROM (Part No. S29L130AFSTB), which retains stored data after the unit power is removed.




- 1.The contents of tuner memory (test state band and frequency), tape counter value and so forth are saved to the EEPROM when the free RAM area is full or a power off process has been completed.
- 2.If the radio is turned on or atape play operation is started subsequently, the PLL processor reads the most recent tuner information from the EEPROM and loads it into its internal RAM.
- 3.This save/load process retains tuner information after the unit power has been switched off.

**A MAIN CIRCUIT** (P.C.Board: on pages 28-31)


**B HEAD CIRCUIT**  
(P.C.Board: on page 29)




Notes: ● → : Playback signal      ● → : Main (Tape/Radio) signal



**A** MAIN CIRCUIT (P.C.Board: on pages 28~31)




- Notes:
- : TV signal
  - : FM signal
  - : AM OSC signal
  - : TV/FM/AM Vcap signal
  - : TV/FM OSC signal
  - : Main (Tape/Radio) signal




Terminal guide: on page 32

Terminal guide: on page 33




Notes: ● → : TV signal    ● □ □ □ → : AM OSC signal    ● □ □ □ → : TV/FM/AM Vcap signal  
 ● → : FM signal    ● □ □ □ → : TV/FM OSC signal

**A** MAIN CIRCUIT (P.C.Board: on pages 28~31)



## Block Diagram



## Terminal Guide of IC's, Transistors and Diodes

	<table border="1"> <tr><td>S29L130AFSTB</td><td>8PIN</td></tr> <tr><td>AN7017SBE2</td><td>16PIN</td></tr> <tr><td>TA7793FNEL</td><td>16PIN</td></tr> <tr><td>LB1674VTLM</td><td>24PIN</td></tr> <tr><td>AN7233SH-E2V</td><td>28PIN</td></tr> </table>	S29L130AFSTB	8PIN	AN7017SBE2	16PIN	TA7793FNEL	16PIN	LB1674VTLM	24PIN	AN7233SH-E2V	28PIN	<p>S8321DNJT2</p>	<p>M34211M4100G</p>	<table border="1"> <tr><td>BA3630AKVE2</td><td>48PIN</td></tr> <tr><td>UPD17073B901</td><td>64PIN</td></tr> </table>		BA3630AKVE2	48PIN	UPD17073B901	64PIN
S29L130AFSTB	8PIN																		
AN7017SBE2	16PIN																		
TA7793FNEL	16PIN																		
LB1674VTLM	24PIN																		
AN7233SH-E2V	28PIN																		
BA3630AKVE2	48PIN																		
UPD17073B901	64PIN																		
	<p>2SA1745-7-TL 2SA1774STL 2SB1219STX 2SB1295-6-TB 2SB1462STX 2SB815B7TX 2SC3931CTX 2SC3935TX</p>	<p>2SC4617STL 2SD1048X7TX 2SD1328STXRA 2SD1819STX 2SD2216STX 2SD2436STXRA DTA115TETL DTA123JETL</p>	<p>DTA125TUT106 UN9110TX UN9115TX UN9116TX UN9210TX UN9215TX UN9216TX</p>	<p>2SK1067-4-TL</p>	<p>LN1271RTR</p>														
<p>MA720TX</p>	<p>MA713TXRA</p>	<p>RVDSVC203ATX KV1560TR2-0</p>	<p>MA728TX</p>	<p>MA729TX</p>	<p>MA8120MTX</p>														

# Printed Circuit Board and Wiring Connection Diagram


This printed circuit board and wiring connection diagram may be modified at any time with development of new technology.)

## Pattern drawing (A) ( layer 1 and 2 )

### Notes:


The printed circuit board consists of four pattern layers.


- The metallization patterns in layers 1 and 2 are shown in pattern drawing (A), and those in layers 3 and 4 are shown in patterns drawing (B).
- In drawings (A) and (B), the visible layers (layers 1 and 4) are printed in black. The invisible layers (layer 2 and 3) are printed in blue.
- Blue dots (⊙) in the drawings indicate through-hole connections between layers 1 and 2 or layers 3 and 4.
- Encircled numbers in the pattern drawings indicate through-hole connections across layers between patterns (A) and (B).  
[ The same number in pattern drawing (A) and (B) indicates the same through-hole connection.]




## A MAIN P.C.B. (REP2401A)

**NOTE:**  
In case that the resistor R411 (5.6kΩ) is not mounted on the P.C.B., install that resistor when servicing.










● Pattern drawing (B) ( layer 3 and 4 )

Notes:

The printed circuit board consists of four pattern layers.

- The metallization patterns in layers 1 and 2 are shown in pattern drawing (A), and those in layers 3 and 4 are shown in patterns drawing (B).
- In drawings (A) and (B), the visible layers (layers 1 and 4) are printed in black. The invisible layers (layer 2 and 3) are printed in blue.
- Blue dots (●) in the drawings indicate through-hole connections between layers 1 and 2 or layers 3 and 4.
- Encircled numbers in the pattern drawings indicate through-hole connections across layers between patterns (A) and (B).  
[ The same number in pattern drawing (A) and (B) indicates the same through-hole connection.]



## Terminal Guide

### ● IC5(UPD17073B901): System control & LCD drive

Pin No.	Mark	I/O	Function
1	CS	O	Chip select signal output terminal.
2	IF REQ	O	IF count control output terminal.
3	RADIO ON	O	Radio power ON output terminal. (RADIO ON: "L")
4	AM	O	Band select (AM) output terminal. (AM: "L")
5	NC	—	Not connected
6	TV:FM	O	Band select (FM) output terminal. (FM: "L")
7	FM/TV	O	Band select (FM/TV) output terminal. (FM/TV: "L")
8	MUTE	O	Muting signal output terminal.
9	EL ON	O	Power control output terminal.
10	DD1 ON	O	DC-DC converter control (ON) output terminal.
11	65V/70F	I	Not used, connected to bias line through resistor.
12	NC	—	Not connected.
13	STOP	I	Key switch (STOP) det. terminal.
14	KEY1	I	Key switch (PLAY, + ,AUTO,RADIO) det. terminal.
15	KEY2	I	Key switch (MODE,MEMO, - ) det. terminal.
16	AD CONT	I	Not used, connected to bias line through resistor.
17	BUZY	I	Beep control input terminal.
18	SD	I	Received signal level det. input terminal.
19	FM/AM IF IN	I	FM/AM IF count signal input terminal.
20	GND	I	GND terminal.
21	GND	I	GND terminal.
22	E.OUT	O	TV/FM/AM Vcap signal output terminal.
23	AM OSC IN	I	AM OSC signal input terminal.
24	FM OSC IN	I	FM OSC signal input terminal.
25	NC	—	Not used, connected to capacitor.
26	VDD	I	Power supply terminal.
27	VDD	I	Power supply terminal.
28	XO	O	Crystal OSC terminal. (F=75kHz)
29	XI	I	
30	NC	O	Not used, connected to capacitor.
31	NC	O	Not used, connected to capacitor.
32	NC	O	Not used, connected to capacitor.

Pin No.	Mark	I/O	Function
33	NC	—	Not used, connected to capacitor.
34	NC	—	Not used, connected to capacitor.
35	C0	O	LCD common signal output terminal.
37	C2		
38	NC	—	Not connected.
39	C3	O	LCD common signal output terminal.
40	S0	O	LCD segment signal output terminal.
44	S4		
45	NC	—	Not connected.
46	S5	O	LCD segment signal output terminal.
53	S12		
54	NC	—	Not connected.
55	S13	O	LCD segment signal output terminal.
56	S14		
57	RES	I	Reset signal input terminal.
58	SD MECA INP	I	Mechanism select signal input terminal.
59	NC	—	Not connected.
60	BEEP	O	Beep control input terminal.
61	SD MECA	O	Mechanism select signal output terminal.
62	SD LCD	I	Remote controller (LCD) control input terminal.
63	SCK	O	Serial clock output terminal.
64	SIO	I/O	Serial data input/output terminal.

## ● IC6 (S29L130AFSTB): EEPROM

Pin No.	Mark	I/O	Function
1	CS	I	Chip select input terminal.
2	SK	I	Serial clock input terminal.
3	DI	I	Serial data input terminal.
4	DO	O	Serial data output terminal.


Pin No.	Mark	I/O	Function
5	GND	—	GND terminal.
6	PROTECT	—	Not used, open.
7	NC	—	Not used, connected to bias line.
8	VDD	I	Power supply terminal.

## ● IC8 (M34211M4100G): Mechanism control

Pin No.	Mark	I/O	Function
1	REV. MODE /B.S	I	B.S/reverse mode select signal input terminal. "L": OFF/ ↶ , "H": ON/ ↷
2	BATT1	I	Battery check det. input terminal.
3	3		
5	BATT4		
6	DC1	O	Not used, connected to GND.
7	DC2		
8	R. CH-F	O	Radio frequency select signal (+) output terminal.
9	R. CH-R	O	Radio frequency select signal (-) output terminal.
10	X OUT	O	Crystal OSC terminal. (F=32.7kHz)
11	X IN	I	
12	CE	I	Chip select terminal. (Connected to bias line.)
13	RST	—	Reset control input terminal.
14	T.END	I	Tape rotation det. signal input terminal. Pulse signal: OK...Mode hold Pulse signal: NG....STOP, R.PLAY
15	SD INT	I	Mechanism select signal terminal.
16	C	I	Not used, open.
17	VDD	I	Power supply terminal.
18	CN VSS	—	GND terminal.
19	VSS	—	GND terminal.
20	LED R	O	Head select ( REV) signal output terminal.
21	REC OUT	—	Not used, connected to GND.
22	REC MUTE	—	Not used, connected to GND.
23	PRE MUTE	O	Muting signal output terminal.
24	POW ON	O	Power ON control output terminal.

Pin No.	Mark	I/O	Function
25	MOTOR	O	Motor power control terminal.
26	CCW	O	Reverse motor control terminal.
27	SPEED	O	Motor speed-up signal output terminal.
28	F/S	O	Motor speed control output terminal.
29	BRAKE	O	Motor brake signal output terminal.
30	SOL	O	Solenoid drive signal output terminal.
31	POW MUTE	O	Muting signal output terminal.
32	ASC	O	ASC EQ control signal output terminal.
33	XBS		
34	RADIO	O	Radio select output terminal.
35	TPS OUT	O	TPS signal output terminal.
36	TPS IN	I	TPS signal input terminal.
37	PL IN	I	Not used, connected to bias line through resistor.
38	A/B DET	I	Tape A/B side det. input terminal (A: "L", B: "H").
39	PH. CONT.	O	Photo coupler power control terminal.
40	T.END1	I	Not used, connected to GND.
41	T.END2		
42	FWD SW	I	Mechanism (FWD) det. input terminal.
43	GND	—	GND terminal.
44	REV. SW	O	Mechanism (REV) det. input terminal.
45	OPEN SW	I	Inputs the signal that detects whether the cassette tape is inserted. "L": ON (CLOSE); the tape is inserted. "H": OFF (OPEN); the tape is not inserted.
46	DD2 CONT	O	DC-DC converter control output terminal.
47	BUZY	I	Beep control input terminal.
48	SD I/O	I/O	Mechanism select signal input terminal.

# ■ Cabinet Parts Location



## Replacement Parts List

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		GABINET AND CHASSIS				TRANSISTOR (S)	
1	RHQ0059-K	SCREW		Q14	2SD2216STX	TRANSISTOR	
2	RHQ0061-K	SCREW		Q15	UN9210TX	TRANSISTOR	
3	RKK0097-1K	BATTERY LID		Q18	2SB1295-6-TB	TRANSISTOR	
4	RMR1009-K	JACK PIECE		Q19	2SC3931CTX	TRANSISTOR	
5	RFKLQXSX25V-K	CASSETTE LID ASS'Y		Q20	2SC3935TX	TRANSISTOR	
6	RHQ0062-K	SCREW		Q21	UN9110TX	TRANSISTOR	
7	RMA0976	LINK ANGLE R		Q22	2SC3935TX	TRANSISTOR	
8	RXMO059	LINK UNIT L		Q23	2SD2216STX	TRANSISTOR	
9	RGK0839A-H	INTERMEDIATE ORNAMENT A		Q24	UN9216TX	TRANSISTOR	
10	RGK0841-H	INTERMEDIATE ORNAMENT C		Q25	2SB1295-6-TB	TRANSISTOR	
11	RGK0849-H	INTERMEDIATE ORNAMENT B		Q26	UN9116TX	TRANSISTOR	
12	RFKNQXSX65V-K	OPEN KNOB ASS'Y		Q27	2SD1819STX	TRANSISTOR	
13	RHE5119YA	SCREW		Q28	2SC3935TX	TRANSISTOR	
14	RHQ0032-K	SCREW		Q29	2SA1745-7-TL	TRANSISTOR	
15	RMA0971	INTERFASE LEVER		Q30	2SC3935TX	TRANSISTOR	
16	RMB0442	AUTO RETURN SPRING		Q31	2SB1295-6-TB	TRANSISTOR	
17	RXQ0479	SHELL LOCK UNIT		Q32	2SB1219STX	TRANSISTOR	
18	XQN14+BG4FZ	SCREW		Q33	2SC3931CTX	TRANSISTOR	
19	RYK0673A-K	CABINET ASS'Y		Q34	UN9215TX	TRANSISTOR	
19A	RGK0850-S	LCD ORNAMENT		Q35	2SC3931CTX	TRANSISTOR	
19B	RGU1429-K	RADIO BUTTON		Q36	2SD2216STX	TRANSISTOR	
19C	RGU1467-S	MECHANISM BUTTON		Q38	DTA115TETL	TRANSISTOR	
19D	RGV0107-K	HOLD KNOB		Q39	2SK1067-4-TL	TRANSISTOR	
19E	RGV0167-K	DOLBY NR KNOB		Q40	UN9116TX	TRANSISTOR	
19F	RGV0180-K	B. S/REV/STEREO MODE KNOB		Q41	2SD2216STX	TRANSISTOR	
20	RGPO570-Q	LCD PANEL		Q43, 44	2SB1462STX	TRANSISTOR	
21	RHQ0022-S	SCREW		Q45	2SD1328STXRA	TRANSISTOR	
22	RHQ0058-Y	SCREW		Q47	UN9115TX	TRANSISTOR	
23	RMA0970	LCD HOLDER		Q48	DTA123JETL	TRANSISTOR	
24	RSQ0050	ZEBRA CONNECTOR		Q50	UN9110TX	TRANSISTOR	
25	RHQ0060-N	SCREW		Q51, 52	2SD2216STX	TRANSISTOR	
26	RJH9208	CONNECTION TERMINAL (S1)		Q53	2SK1067-4-TL	TRANSISTOR	
27	RJC99027	R. BATTERY TERMINAL (+)		Q56	2SD2216STX	TRANSISTOR	
28	RJC99028	R. BATTERY TERMINAL (-)		Q57	2SA1774STL	TRANSISTOR	
29	RJR0154-1	R. BATTERY SHAFT		Q58	2SC4617STL	TRANSISTOR	
30	RHQ0013-1	SCREW		Q59	2SA1774STL	TRANSISTOR	
		INTEGRATED CIRCUIT (S)		Q60	2SD1819STX	TRANSISTOR	
IC1	AN7017SBE2	IC		Q61	UN9116TX	TRANSISTOR	
IC4	AN7233SH-E2V	IC		Q62	2SD2216STX	TRANSISTOR	
IC5	UPD17073B901	IC		Q63	UN9210TX	TRANSISTOR	
IC6	S29L130AFSTB	IC		Q64	2SD2436STXRA	TRANSISTOR	
IC7	BA3630AKVE2	IC		Q65	2SB815B7TX	TRANSISTOR	
IC8	M34211M4100G	IC		Q66	UN9210TX	TRANSISTOR	
IC11	S8321DNJT2	IC		Q67	2SD1048X7TX	TRANSISTOR	
IC12	TA7793FNEL	IC		Q68	2SB1295-6-TB	TRANSISTOR	
IC401	LB1674VILM	IC		Q69	2SD1819STX	TRANSISTOR	
				Q71	UN9210TX	TRANSISTOR	
				Q72	2SD2216STX	TRANSISTOR	
				Q73	DTA125TUT106	TRANSISTOR	
				Q74	2SD2216STX	TRANSISTOR	

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
Q75	2SA1745-7-TL	TRANSISTOR		L22	RL09U006-M	COIL	
Q76, 77	UN9215TX	TRANSISTOR		L23	RLQP100KT2-Y	COIL	
Q301	UN9110TX	TRANSISTOR				FILTER(S)	
Q311	2SD2216STX	TRANSISTOR					
Q312	UN9215TX	TRANSISTOR		CF1, 2	RLFGECWNO4AL	FM IF FILTER	
Q313	UN9116TX	TRANSISTOR		CF3	RLFEFCFM3450A	AM FILTER	
Q371	2SD2216STX	TRANSISTOR		CF4	RLFDG001AL	FM FILTER	
Q372	UN9215TX	TRANSISTOR				DISPLAY	
Q401	UN9116TX	TRANSISTOR					
Q801	DTA123JETL	TRANSISTOR		LCD1	RSL5161-C	LCD DISPLAY	
Q802, 803	UN9210TX	TRANSISTOR				OSCILLATOR(S)	
Q804	DTA123JETL	TRANSISTOR					
Q805, 806	UN9210TX	TRANSISTOR					
		DIODE(S)		X1	RSXC32K7L01T	OSCILLATOR	
D7	LN1271RTR	L. E. D.		X2	RSXC75K0L02T	OSCILLATOR	
D8, 9	RVDSVC203ATX	DIODE				TRIMMER(S)	
D10	RVDSVC203ATX	DIODE					
D11	KV1560TR2-0	DIODE		CT1	RCVCFA20C01L	TRIMMER(FM RF)	
D12	MA729TX	DIODE		CT2	RCVCFA10C01L	TRIMMER(TV RF)	
D13	MA720TX	DIODE				PHOTO COUPLER(S)	
D14	MA8120MTX	DIODE					
D15	MA729TX	DIODE		P1	GP2S27T6	PHOTO COUPLER	
D17	MA713TXRA	DIODE				SWITCH(ES)	
D20	MA728TX	DIODE					
		VARIABLE RESISTOR(S)		S1	RSH1A040-A	SWITCH	
VR1	EVUTOVA05A54	V. R		S3, 4	EVQPSR02K	SWITCH	
VR3	EVM3SSX50B14	V. R		S5	EVQPLMA15	SWITCH	
VR402	EVM1CSX10B23	V. R		S7-11	EVQPLMA15	SWITCH	
		COMPONENT COMBINATION(S)		S12	RSH1B011-1U	SWITCH	
				S15	RSS2A010-1A	SWITCH	
Z1	RCRBTC002-D	FM/TV B. P. F		S16	RSS2A012-1A	SWITCH	
		COIL(S)		S17, 18	RSS2A010-1A	SWITCH	
						CONNECTOR(S)	
L6	RL04Z026T-W	COIL		CN1	RJS2A1606T	CONNECTOR(6P)	
L7	RL04Z015T-W	COIL				JACK(S)	
L8	RL04Z027T-W	COIL					
L9	RL04Z025T-W	COIL					
L10	RL02U025T-M	COIL		JK1	RJJ36TK03-C	HEADPHONES	
L12	RLV2N046-0	COIL (FERRITE ANT)					
L12	RLBV601V-W	COIL					
L13	RLBN601V-W	COIL					
L14, 15	RLBV601V-W	COIL					
L16, 17	RLBN601V-W	COIL					
L19	RLQU331KT-W	COIL					
L20	RLQM101K-W	COIL					
L21	RLQM2R2M-W	COIL					

## Resistors and Capacitors

**Notes:** \* Capacity values are in microfarads ( $\mu\text{F}$ ) unless specified otherwise, P=Pico-farads (pF) F=Farads (F)  
\* Resistance values are in ohms, unless specified otherwise, 1K=1,000 (OHM), 1M=1,000k (OHM)

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
		RESISTORS	R86	ERJ2GEJ332X	1/16W 3.3K	R152	ERJ3GEYJ334V	1/16W 330K
			R87	ERJ2GEJ822X	1/16W 8.2K	R153	ERJ2GEJ104X	1/16W 100K
			R88	ERJ2GEJ153X	1/16W 15K	R154	ERJ2GEJ473X	1/16W 47K
R5	ERJ3GEYJ224V	1/16W 220K	R89	ERJ2GEJ474X	1/16W 470K	R155	ERJ2GEJ223X	1/16W 22K
R9	ERJ3GEYJ151V	1/16W 150	R90	ERJ3GEYJ224V	1/16W 220K	R156	ERJ3GEYJ471V	1/16W 470
R10	ERJ3GEYJ153V	1/16W 15K	R91	ERJ2GEJ332X	1/16W 3.3K	R157	ERJ3GEYJ104V	1/16W 100K
R11	ERJ2GEJ472X	1/16W 4.7K	R92	ERJ2GEJ471X	1/16W 470	R158	ERJ2GEJ474X	1/16W 470K
R12	ERJ2GEJ221X	1/16W 220	R93	ERJ2GEJ473X	1/16W 47K	R159	ERJ3GEYD334V	1/16W 330K
R13	ERJ2GEJ222X	1/16W 2.2K	R94	ERJ2GEJ513X	1/16W 51K	R160	ERJ2GEJ102X	1/16W 1K
R14	ERJ2GEJ682X	1/16W 6.8K	R95	ERJ3GEYJ682V	1/16W 6.8K	R161	ERJ3GEYD204V	1/16W 200K
R15	ERJ2GEJ472X	1/16W 4.7K	R96	ERJ2GEJ821X	1/16W 820	R165	ERJ2GEJ104X	1/16W 100K
R16	ERJ2GEJ221X	1/16W 220	R97	ERJ2GEJ101X	1/16W 100	R166	ERJ2GEJ474X	1/16W 470K
R18	ERJ2GEJ332X	1/16W 3.3K	R101	ERJ3GEYJ152V	1/16W 1.5K	R167	ERJ3GEYJ471V	1/16W 470
R20	ERJ2GEJ221X	1/16W 220	R102, 103	ERJ3GEYD393V	1/16W 39K	R168	ERJ2GEJ474X	1/16W 470K
R21	ERJ3GEYJ153V	1/16W 15K	R104	ERJ2GEJ332X	1/16W 3.3K	R169	ERJ2GEJ331X	1/16W 330
R23	ERJ2GEJ472X	1/16W 4.7K	R106	ERJ2GEJ823X	1/16W 82K	R170	ERJ2GEJ470X	1/16W 47
R24	ERJ2GEJ274X	1/16W 270K	R107	ERJ3GEYJ823V	1/16W 82K	R171	ERJ3GEYJ333V	1/16W 33K
R25	ERJ2GEJ181X	1/16W 180	R108	ERJ2GEJ221X	1/16W 220	R172	ERJ2GEJ472X	1/16W 4.7K
R26	ERJ2GEJ103X	1/16W 10K	R109	ERJ2GEJ103X	1/16W 10K	R173	ERJ2GEJ332X	1/16W 3.3K
R27	ERJ2GEJ472X	1/16W 4.7K	R110	ERJ2GEJ102X	1/16W 1K	R174	ERJ2GEJ474X	1/16W 470K
R28	ERJ2GEJ222X	1/16W 2.2K	R111	ERJ3GEYJ332V	1/16W 3.3K	R177, 178	ERJ2GEJ104X	1/16W 100K
R29	ERJ2GEJ102X	1/16W 1K	R112	ERJ3GEYJ153V	1/16W 15K	R180	ERJ2GEJ474X	1/16W 470K
R30	ERJ2GEJ153X	1/16W 15K	R113	ERJ2GEJ512X	1/16W 5.1K	R182	ERJ3GEYJ474V	1/16W 470K
R32	ERJ2GEJ682X	1/16W 6.8K	R114	ERJ2GEJ101X	1/16W 100	R183	ERJ2GEJ104X	1/16W 100K
R35	ERJ2GEJ151X	1/16W 150	R115	ERJ3GEYJ224V	1/16W 220K	R184	ERJ3GEYD243V	1/16W 24K
R40	ERJ2GEJ224X	1/16W 220K	R116	ERJ2GEJ512X	1/16W 5.1K	R185	ERJ3GEYD183V	1/16W 18K
R45	ERJ2GEJ474X	1/16W 470K	R118	ERJ3GEYJ474V	1/16W 470K	R186	ERJ3GEYJ473V	1/16W 47K
R47	ERJ2GEJ220X	1/16W 22	R119	ERJ2GEJ103X	1/16W 10K	R187	ERJ3GEYD243V	1/16W 24K
R49	ERJ2GEJ392X	1/16W 3.9K	R120	ERJ3GEYJ224V	1/16W 220K	R188	ERJ3GEYD183V	1/16W 18K
R51	ERJ2GEJ392X	1/16W 3.9K	R121	ERJ3GEYJ103V	1/16W 10K	R191	ERJ2GEJ473X	1/16W 47K
R52	ERJ3GEYJ474V	1/16W 470K	R122	ERJ2GEJ682X	1/16W 6.8K	R192	ERJ3GEYD243V	1/16W 24K
R55	ERJ2GEJ683X	1/16W 68K	R123	ERJ3GEYJ224V	1/16W 220K	R193	ERJ3GEYD183V	1/16W 18K
R56	ERJ3GEYJ1R2V	1/16W 1.2	R124	ERJ2GEJ472X	1/16W 4.7K	R195	ERJ2GEJ221X	1/16W 220
R57	ERJ2GEJ474X	1/16W 470K	R125	ERJ2GEJ101X	1/16W 100	R200, 201	ERJ2GEJ153X	1/16W 15K
R58	ERJ2GEJ683X	1/16W 68K	R126, 127	ERJ3GEYJ474V	1/16W 470K	R301, 302	ERJ2GEJ333X	1/16W 33K
R59	ERJ3GEYJ1R2V	1/16W 1.2	R129	ERJ3GEYK106V	1/16W 10M	R303	ERJ2GED222X	1/16W 2.2K
R60-62	ERJ2GEJ474X	1/16W 470K	R131	ERJ2GEJ334X	1/16W 330K	R304	ERJ2GEJ133X	1/16W 13K
R63	ERJ2GEJ683X	1/16W 68K	R133	ERJ2GEJ681X	1/16W 680	R305	ERJ2GEJ394X	1/16W 390K
R64	ERJ2GEJ4R7X	1/16W 4.7	R136, 137	ERJ2GEJ474X	1/16W 470K	R306	ERJ2GEJ183X	1/16W 18K
R65	ERJ2GEJ331X	1/16W 330	R138, 139	ERJ2GEJ103X	1/16W 10K	R311	ERJ2GEJ101X	1/16W 100
R68	ERJ2GEJ474X	1/16W 470K	R141	ERJ3GEYJ473V	1/16W 47K	R312	ERJ2GEJ472X	1/16W 4.7K
R70	ERJ2GEJ474X	1/16W 470K	R142	ERJ2GEJ473X	1/16W 47K	R313	ERJ2GEJ223X	1/16W 22K
R71	ERJ2GEJ224X	1/16W 220K	R143	ERJ3GEYJ474V	1/16W 470K	R314	ERJ3GEYJ104V	1/16W 100K
R72	ERJ2GEJ103X	1/16W 10K	R145	ERJ3GEYJ154V	1/16W 150K	R361, 362	ERJ2GEJ333X	1/16W 33K
R73	ERJ3GEYJ473V	1/16W 47K	R146	ERJ2GEJ474X	1/16W 470K	R363	ERJ2GED222X	1/16W 2.2K
R74	ERJ2GEJ474X	1/16W 470K	R147	ERJ2GEJ223X	1/16W 22K	R364	ERJ2GEJ133X	1/16W 13K
R76	ERJ2GEJ152X	1/16W 1.5K	R148	ERJ2GEJ473X	1/16W 47K	R365	ERJ2GEJ394X	1/16W 390K
R77	ERJ2GEJ473X	1/16W 47K	R149	ERJ3GEYJ104V	1/16W 100K	R371	ERJ2GEJ101X	1/16W 100
R85	ERJ2GEJ152X	1/16W 1.5K	R151	ERJ3GEYJ124V	1/16W 120K	R372	ERJ2GEJ472X	1/16W 4.7K


Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
R373	ERJ3GEYJ223V	1/16W 22K	C80	ECUVNC104ZV	16V 0.1U	C174	ECUE1H181KBQ	50V 180P
R403	ERJ2GEJ562X	1/16W 5.6K	C84	ECUV1H391GCV	50V 390P	C175	RCST0EA475RE	2.5V 4.7U
R404	ERAS15ZJ103V	1/10W 10K	C88	ECUVNC104ZV	16V 0.1U	C176	ECUV0J105ZV	6.3V 1U
R405	ERJ2GEJ331X	1/16W 330	C89, 90	RCST0EA685RE	2.5V 6.8U	C177	ECUVNC473KBV	16V 0.047U
R407	ERJ2GEJ222X	1/16W 2.2K	C91	ECUE1C104ZV	16V 0.1U	C178	ECUV1C683KBV	16V 0.068U
R409	ERJ2GEJ102X	1/16W 1K	C93	ECUVNE183KBV	25V 0.018U	C179	ECUV1C104KBV	16V 0.1U
R410	ERJ2GEJ123X	1/16W 12K	C94	ECUE1H102KBQ	50V 1000P	C180	RCUV1C223KBV	16V 0.022U
R411	ERJ2GEJ562X	1/16W 5.6K	C96	ECUVNE183KBV	25V 0.018U	C181	ECUVNC105ZFN	16V 1U
R801	ERJ2GEJ471X	1/16W 470	C97, 98	ECST0EX107RR	2.5V 100U	C182	ECUV1C104KBV	16V 0.1U
			C100	ECUVNH103KBV	50V 0.01U	C183	ECUE1H680JCQ	50V 68P
		CHIP JUMPERS	C102	ECUE1C103KBQ	16V 0.01U	C184	ECUE1H331KBQ	50V 330P
			C105	RCUV1C223KBV	16V 0.022U	C185	ECUVNE153KBV	25V 0.015U
J100	ERJ3GEYOR00V	CHIP JUMPER	C106	ECUVNC334KBN	16V 0.33U	C186	ECUV1H681KCN	50V 680P
			C107	ECUE1H102KBQ	50V 1000P	C187	ECUVNE153KBV	25V 0.015U
		CAPACITORS	C108	ECUVNC334KBN	16V 0.33U	C188, 189	ECUVNC473KBV	16V 0.047U
			C109	ECUV1H331KBV	50V 330P	C191	ECST1CY155RR	16V 1.5U
C10	ECUE1C103KBQ	16V 0.01U	C110	ECUE1H331KBQ	50V 330P	C192	ECUE1H102KBQ	50V 1000P
C11	ECUE1H102KBQ	50V 1000P	C111	ECUV1H470GCV	50V 47P	C193	ECUE1H331KBQ	50V 330P
C12	ECUVNH103KBV	50V 0.01U	C112	ECUE1H101KBQ	50V 100P	C194	ECST0EY336RR	2.5V 33U
C13, 14	ECUE1H102KBQ	50V 1000P	C114	ECUV1H221GCV	50V 220P	C195	ECUE1H050DCQ	50V 5P
C15	ECUVNH103KBV	50V 0.01U	C115	ECUE1H020CCQ	50V 2P	C196	ECUE1H120JCQ	50V 12P
C16	ECUE1H102KBQ	50V 1000P	C116	ECUE1H1032FQ	50V 0.01U	C197	RCSX0GY226RE	4V 22U
C17	ECUE1E472KBQ	25V 4700P	C117	ECUV1H221GCV	50V 220P	C198, 199	ECUE1H050DCQ	50V 5P
C18-21	ECUE1H102KBQ	50V 1000P	C118	RCUV1C223KBV	16V 0.022U	C200-203	ECUVNC104ZV	16V 0.1U
C22	ECUE1H681KBQ	50V 680P	C119	ECUVNC104ZV	16V 0.1U	C204	ECUE1H102KBQ	50V 1000P
C23	ECST0EY336RR	2.5V 33U	C120	ECUV1H560GCV	50V 56P	C205	ECUVNC104ZV	16V 0.1U
C24	ECUV0J105ZV	6.3V 1U	C121, 122	RCUV1C223KBV	16V 0.022U	C206	RCST0JA335RE	6.3V 3.3U
C25	ECST0GY156RR	4V 15U	C127	ECUE1H020CCQ	50V 2P	C207	RCST0EA475RE	2.5V 4.7U
C26	RCST0EA475RE	2.5V 4.7U	C128	ECUE1H070DCQ	50V 7P	C208	RCST0GZ335RE	4V 3.3U
C28	RCUV1C223KBV	16V 0.022U	C129	ECUE1H120JCQ	50V 12P	C209	ECUVNC224KBN	16V 0.22U
C29, 30	ECUE1H331KBQ	50V 330P	C130	ECUV1H102KBV	50V 1000P	C210	ECUVNC104ZV	16V 0.1U
C33	ECUV1C224ZV	16V 0.22U	C133	ECUV1H560GCV	50V 56P	C211	ECUV0J105ZV	6.3V 1U
C36	RCST0JA225RE	6.3V 2.2U	C135	ECUE1H331KBQ	50V 330P	C212	RCST0JA335RE	6.3V 3.3U
C37	ECUVNE153KBV	25V 0.015U	C137	ECUE1H331KBQ	50V 330P	C213	ECUE1H222KBQ	50V 2200P
C39	ECUVNC104ZV	16V 0.1U	C147	RCST0EA475RE	2.5V 4.7U	C214	ECUVNH103KBV	50V 0.01U
C44	ECUVNE153KBV	25V 0.015U	C149	ECUE1C103KBQ	16V 0.01U	C215	ECUVNC104ZV	16V 0.1U
C45	RCST0JA225RE	6.3V 2.2U	C150	RCUV1C333KBV	16V 0.033U	C216	ECUV0J105ZV	6.3V 1U
C49	RCUV1C223KBV	16V 0.022U	C151	ECUVNC104ZV	16V 0.1U	C217	RCST0EA475RE	2.5V 4.7U
C50	ECUV1C224ZV	16V 0.22U	C153	ECUV1H391GCV	50V 390P	C218	ECUV0J105ZV	6.3V 1U
C55	ECST0EY336RR	2.5V 33U	C154	ECUE1H220JCQ	50V 22P	C219	ECUV1H472KBV	50V 4700P
C58	ECUE1H152KBQ	50V 1500P	C155	ECUVNE153KBV	25V 0.015U	C224	ECUE1H101KBQ	50V 100P
C59	ECUV0J105ZV	6.3V 1U	C156	ECUE1H070DCQ	50V 7P	C225	ECUV0J105ZV	6.3V 1U
C60	ECUV1C104KBV	16V 0.1U	C158	ECUE1H050DCQ	50V 5P	C226	ECUE1H331KBQ	50V 330P
C63	ECUE1H152KBQ	50V 1500P	C159	ECUV1H331KBV	50V 330P	C227	ECUV1C104KBV	16V 0.1U
C64	ECUV0J105ZV	6.3V 1U	C160	ECUE1C103KBQ	16V 0.01U	C229	ECUE1H101KBQ	50V 100P
C65	RCST0EA475RE	2.5V 4.7U	C162	RCUV1C223KBV	16V 0.022U	C230	ECUV1C104KBV	16V 0.1U
C67	ECUVNC105KBM	16V 1U	C163	ECUE1H1032FQ	50V 0.01U	C232	ECUE1H101KBQ	50V 100P
C68	RCSX0GY106RE	4V 10U	C164	ECUVNC104ZV	16V 0.1U	C233	ECUVNC104ZV	16V 0.1U
C69	RCUV1C154KBN	16V 0.15U	C170	ECUE1H1032FQ	50V 0.01U	C234	RCUV1C223KBV	16V 0.022U
C71	ECUVNC105ZFN	16V 1U	C171	ECUE1C103KBQ	16V 0.01U	C235	ECUE1H331KBQ	50V 330P
C72	ECST0EY336RR	2.5V 33U	C172	ECUV0J105ZV	6.3V 1U	C301	ECUE1H332KBQ	50V 3300P
C74	ECUVNC104ZV	16V 0.1U	C173	RCST0JA225RE	6.3V 2.2U	C302	ECUE1C822KBQ	16V 8200P

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
C303	ECUVNC105ZFN	16V 1U	C363	ECUVNC105ZFN	16V 1U	C403	ECUV1C104KBV	16V 0.1U
C304	ECUV0J105ZFV	6.3V 1U	C364	ECUV0J105ZFV	6.3V 1U	C404	EGST1AY225RR	10V 2.2U
C305	ECUE1C103KBQ	16V 0.01U	C365	ECUE1C103KBQ	16V 0.01U	C408	ECUVNC334KBN	16V 0.33U
C306	ECUV1A474ZV	10V 0.47U	C366	ECUV1A474ZV	10V 0.47U	C801	ECUE1H221KBQ	50V 220P
C311	RCUV1C223KBV	16V 0.022U	C367	ECST0GY156RR	4V 15U	C802	ECUE1H102KBQ	50V 1000P
C312	ECUE1C562KBQ	16V 5600P	C371	RCUV1C223KBV	16V 0.022U	C803	ECUE1H221KBQ	50V 220P
C361	ECUE1H332KBQ	50V 3300P	C372	ECUE1C562KBQ	16V 5600P	C810-812	ECUE1H331KBQ	50V 330P
C362	ECUE1C822KBQ	16V 8200P	C402	ECUVNC474KBN	16V 0.47U			

### Mechanism Parts Location

Item	FWD & REV mode
Wow and flutter	0.3 % (WRMS)
Pressure of pinch roller	110±10 g
Take-up tension	More than 60 g
Playback torque	20±5 g
FF/REW torque	More than 60 g · cm

The parts enclosed in the dotted boxes are supplied as a block assembly. Therefore, they are not supplied separately except parts indicated with Ref. No.



### Replacement Parts List

**Notes:** \* Important safety notice:  
 Components identified by  $\Delta$  mark have special characteristics important for safety.  
 Furthermore, special parts which have purposes of fire-retardant (resistors), high-quality sound (capacitors), low-noise (resistors), etc. are used.  
 When replacing any of components, be sure to use only manufacturer's specified parts shown in the parts list.

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		MECHANISM		106	RXQ0445	HEAD BLOCK ASS'Y	
				106A	RXL0130	PINCH ROLLER ARM(F)	
				106B	RME0187-1	HEAD ARM SPRING	
				106C	RXL0131	PINCH ROLLER ARM(R)	
101	BFL26NB1AT	MOTOR		107	RFKRQSN55-K	MECHANISM BLOCK ASS'Y	
102	XQS14+A2FZ	SCREW		107A	RMQ0547	HOLD PIECE (F)	
103	RHW40002	WASHER		107B	RHD14047	SCREW	
104	RDV0037	CAPSTAN BELT(1)		107C	RMQ0548	HOLD PIECE (R)	
105	RDV0044	CAPSTAN BELT(2)					

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		PACKING MATERIAL		A5	RFEV001PVKS	REMOTE CONTROLLER	
				A6	RFEV316P-KS	STEREO EARPHONES	
				A7	RP-BC155AEY	CHARGER	△
P1	RPK0816	PACKING CASE		A8	RQCB0169	SERVICENTER LIST	
P2	RPQ0575	PAD		A9 ※	RKB205ZA-0	EAR PADS	
P3	RPQ0581-1	SPACER				<PRINTED CIRCUIT BOARDS ASS'Y>	
		ACCESSORIES		PCB1	REP2401A	MAIN P. C. B. ASS'Y	(RTL)
A1	RQT3683-G	INSTRUCTION MANUAL				<GREASE OR JIG/TOOL>	
A2	RP-BP61SYS1	RECHARGEABLE BATTERY				TEST TAPE	
A2-1	RFA0475-Q	R. BATTERY CARRYING CASE		SA1	QZZCWAT	TAPE SPEED ADJ.	
A3	RFA0617-H	DRY CELL BATTERY CASE					
A3-1	RKK0071-H	DRY CELL BATTERY COVER					
A4	RFC0043A-K	CARRYING BAG					

※ This item is not attached merchandise, but it is supplied as a replacement part.

- The marking (RTL) indicates that the Retention Time is limited for this item. After the discontinuation of this assembly in production, the item will continue to be available for a specific period of time. The retention period of availability is dependant on the type of assembly, and in accordance with the laws governing part and product retention. After the end of this period, the assembly will no longer be available.

## Supply of Rechargeable Battery as Replacement Parts



Please take note of the following points relating to Carrying Case to be used for protection of Rechargeable Battery from shorting.

Replacement Parts:

- Rechargeable Battery (RP-BP61SYS1) to be supplied will be provided with Carrying Case (RFA0475-Q).
- No replacement parts will be supplied for Rechargeable Battery without Carrying Case.
- Replacement parts will be supplied for Carrying Case (RFA0475-Q) without Rechargeable Battery.
- To your customers, delivery Rechargeable Battery together with Carrying Case to prevent shorting accidents that may occur when Rechargeable Battery is carried about without Carrying Case.

## Caution in Use of Rechargeable Battery

- Take Rechargeable Battery out of Carrying Case and use it.
- Be sure to carry Rechargeable Battery in this Carrying Case. If not, it may either heat or ignite by shorting with a metal.



## Packaging

