

SW NO	FUNCTION	POSITION
SW1(A~F)	BAND SELECTOR	FM-LW-MW-SW
SW101(A~F)	FUNCTION SELECTOR	TAPE - RADIO
SW102(A~J)	RECORD/PLAYBACK	RECORD - PLAYBACK
SW103	BEAT CANCEL	A - B - C
SW104	MODE SELECTOR	FM MONO-STEREO - ST WIDE
SW301	AC/DC SELECTOR	AC - DC
SW401	MAIN	ON - OFF

* Wiring diagram of this model is subject to change for the improvement without prior notice.