


SYMBOL-NO	P-NO	DESCRIPTION	SYMBOL-NO	P-NO	DESCRIPTION
CAPACITORS					
CT101	5054041	VARIABLE	D449	5330721	DIODE GERMANIUM 1N34A 10MHZ 50HM
CT102	5054041	VARIABLE	D467	5330731	DIODE GERMANIUM 1N60 80MHZ 50HM
CT151	0283577	TRIMMER 8PF	D488	5330731	DIODE GERMANIUM 1N60 80MHZ 50HM
CT152	0283577	TRIMMER 8PF	D411	0575005	DIODE GERMANIUM 1N60 80MHZ 50HM 70NS
CT153	0283577	TRIMMER 8PF	D412	0575005	DIODE GERMANIUM 1N60 80MHZ 50HM 70NS
CT154	0283577	TRIMMER 8PF	D461	5330731	DIODE 3V-018
CT155	0283577	TRIMMER 8PF	D462	5330731	DIODE 3V-028
CT156	0283577	TRIMMER 8PF	IC801	5584611	IC TRY-1002
CV101	5054041	VARIABLE	IC802	5581061	IC AN25988
CV102	5054041	VARIABLE	IC801	5581141	IC LA3501
CV151	5054041	VARIABLE	IC401	5580871	IC TAI099
CV152	5054041	VARIABLE	IC501	5580402	IC LA4102
CV158	0246430	CERAMIC, DISCAL 10PF 0.5PF	IC502	5580402	IC LA4102
C110	0246425	CERAMIC DISCAL 9P-0	Q101	5521422	TRANSISTOR 25C49F1
C111	0246443	CERAMIC DISCAL 13PF+-5% TRK-5190E(AU), E(AU)	Q102	5521271	TRANSISTOR SILICON 25C167AL 600MHZ 250HM
C111	0246444	CERAMIC DISCAL 15PF+-5% TRK-5190E	Q151	5521271	TRANSISTOR SILICON 25C167AL 600MHZ 250HM
RESISTORS			Q401	5521291	TRANSISTOR 25C1740R
RC201	0186001	CR PACK 10KHM 10K 0.01PF+-50M X2	Q402	5521291	TRANSISTOR 25C1740R
RC202	0186357	CR PACK	Q403	5521032	TRANSISTOR 25C1339E
RC601	0186451	CR PACK	Q404	5521032	TRANSISTOR 25C1339E
RC602	0186451	CR PACK	Q405	5520066	TRANSISTOR SILICON 25C49BD 250MHZ 200HM
RT301	0151800	SEMI VARIABLE 10KHM 8	Q406	5520066	TRANSISTOR SILICON 25C49BD 250MHZ 200HM
RV401	0151807	SEMI VARIABLE 500 OHM RESHM	Z0401	5530593	ZENER DIODE SILICON HZAC 1MHZ
RV401	5000133	VARIABLE 10KOHM (8)	TRANSFORMERS		
RV402	5000133	VARIABLE 10KOHM (8)	PT	5211921	POWER XVA-4006 TRK-5190E
RV403	5000133	VARIABLE 10KOHM (8)	PT	5211926	POWER XVA-4006 (851 TRK-5190E(85), E(AU)
RV404	5000292	VARIABLE 10KOHM(A)	PT	5211925	POWER TRK-5190E(M)
RV405	5000292	VARIABLE 10KOHM(A)	T101	5140017	FM IF
RV406	5000272	VARIABLE 10KOHM(B)	T151	5120034	AM IF
RV407	5000272	VARIABLE 10KOHM(B)	T152	5120031	AM IF 2KOHM 1 SKOHM
RV408	5000282	VARIABLE 50KOHM(B)	T201	5140016	FM IF
SEMI-CONDUCTORS			T202	5150035	AM IF
D101	5330571	DIODE SILICON 1S2473VE	T203	5140012	DISCRIMINATOR-1ST
D102	5330571	DIODE SILICON 1S2473VE	T204	5140034	FM IF
D103	5330591	DIODE SC-15 TRK-5190E(M)	T205	5140019	FM IF
D103	5330661	DIODE SILICON LS2770 200MHZ 80HM TRK-5190E . E(AU)	COILS		
D151	5330721	DIODE GERMANIUM 1N34A 10MHZ 50HM	L001	0333121	TRAP
D201	5330721	DIODE GERMANIUM 1N34A 10MHZ 50HM	L101	5120081	FM ANT TRK-5190E, E(M)
D202	5330731	DIODE GERMANIUM 1N60 80MHZ 50HM	L101	5120461	FM ANT TRK-5190E(AU)
D203	0575005	DIODE GERMANIUM 1N60 80MHZ 50HM 70NS	L104	5120008	FM RF 0.5 MICROH
D204	5330731	DIODE GERMANIUM 1N60 80MHZ 50HM	L109	5123271	FM TRAP 8.5HM
D205	5330731	DIODE GERMANIUM 1N60 80MHZ 50HM	L100	5126278	FM OSC
D206	5330732	DIODE GERMANIUM 1N60P 80MHZ 50HM	L151	5112016	FERRITE CORE ANTENNA
D207	5330732	DIODE GERMANIUM 1N60P 80MHZ 50HM	L152	5112016	FERRITE CORE ANTENNA
D401	5330572	DIODE SILICON 1S2473MC 100MHZ 250HM 10NS	L153	5123941	SW ANTENNA
D402	5330572	DIODE SILICON 1S2473MC 100MHZ 250HM 10NS	L154	5123271	FM TRAP 8.5HM
D403	5330721	DIODE GERMANIUM 1N34A 10MHZ 50HM	L155	5120063	LW-OSC

SYMBOL-NO	P-NO	DESCRIPTION	SYMBOL-NO	P-NO	DESCRIPTION
COILS			J 6	5679371	JACK PLATE
L156	5120319	OSC	J 7	5679371	JACK PLATE
L157	5129423	SW-OSC	J 8	5679371	JACK PLATE
L158	5152031	CHOKE 100HM	J 9	5670453	HEAD PHONE JACK TRK-5190E, E(M)
L201	5152023	CHOKE 47HM	J 9	5670454	HEAD PHONE JACK TRK-5190E(AU)
L301	5161561	HP FILTER	J10	5679371	JACK PLATE
L303	5120189	38KHZ TUNER	LH18AT	5584175	LEVEL METER
L304	5120189	38KHZ TUNER	LH1TUN	5584176	LEVEL METER
L401	5120302	TRAP 35HM	MIC	9421211	MICROPHONE
L402	5120302	TRAP 35HM	OSC401	5280631	OSC BLOCK
L601	5152123	CHOKE 18HM	PL	5760826	LAMP
L602	5152123	CHOKE 18HM	S 1	5625011	SLIDE SWITCH
MISCELLANEOUS			S 2	5623901	SLIDE SWITCH
5652041	AC SOCKET TRK-5190E		S 3	5620382	SLIDE SWITCH
5652002	AC SOCKET TRK-5190E(E(AU)		S 4	5633161	PUSH SWITCH
5752221	ROD ANTENNA		S 5	5633161	PUSH SWITCH
5160211	CERAMIC FILTER CF107A		S 6	5633161	PUSH SWITCH
F601	0591160	FUSE 0.5A TRK-5190E	S 7	5623291	SLIDE SWITCH
5720175	FUSE 0.5A TRK-5190E(AU)		S 8	5603112	LEAF SWITCH
J 1	5679371	JACK PLATE	SP	5401511	SPEAKER-5CM
J 2	5679371	JACK PLATE	SP	5405062	SPEAKER-10CM
J 3	5679371	JACK PLATE	S10	5639023	VOLTAGE CHANGE-OVER SWITCH TRK-5190E M
J 4	5660641	5P DIM CONNECTOR			
J 5	5679371	JACK PLATE			



Head Office : 5-1, 1 chome, Marunouchi, Chiyoda-ku, Tokyo
Tel. Tokyo (212) 1111 (80 lines)

Cable Address: "HITACHY" TOKYO

Codes : All Codes Used

HITACHI SALES EUROPA GmbH

2 Hamburg 54, Kleine Bahnstraße 8, West Germany

Tel. : 850 60 71-75

HITACHI SALES (U.K.) Ltd.

Hitachi House, Station Road, Hayes, Middlesex UB3 4DR, England

Tel. : 01-848-8787 (Service Centre: 01-848-3551)

HITACHI SALES SCANDINAVIA AB

Rissneleden 8, Sundbyberg, Box 7138, S-172-07 Sundbyberg 7, Sweden

Tel. : 08-98 52 80

HITACHI SALES NORWAY A/S

Nygaardsgt. 49/51, N-1600 Fredrikstad, Norway

Tel. : Fredrikstad 11 140

SUOMEN HITACHI OY

Box 151, SF-15100 Lahti 10, Finland

Tel. : Lahti 44 241

HITACHI SALES A/S

Kuldysen 13, DK-2630 Taastrup, Denmark

Tel. : 02-999200

HITACHI SALES A.G.

5600 Lenzburg, Switzerland

Tel. : 064-513621

HITACHI-FRANCE (Radio-Télévision Electro-Ménager) S.A.

9, Boulevard Ney 75018, Paris, France

Tel. : 201-25-00

